


Teepee Assembly Instructions

(Registered Design 4002874) Please retain this document for future reference.


Please fold all creases well prior to assembly of toy and ensure all parts are securely connected.

Step 1



- Insert tabs (A1) on each part into the corresponding slots (B1) on the part next to it (order of pieces as shown above). Once each tab is inserted gently bend the smaller flaps on tabs (B1) inwards to ensure a secure fit. Once joined together, connect each end to form an octagonal shape.

Step 2



- Push the octagonal insert up inside the assembled teepee horizontally until tight. The notches on the insert fit into the top slots (A2) on each of the panels to help secure the teepee shape.

The teepee is designed primarily for indoor use but is also suitable for outdoor use in dry, calm conditions. The teepee should be stored in a dry place and should be kept away from fire or any naked flame. The teepee should be inspected regularly before, during and after use for any signs of damage, which could cause potential injury.

WARNING : This product should be kept out of the reach of very young children and only be used under the direct supervision of an adult.